



# EZSLAM

## INSTALLATION/SOFTWARE/USAGE

### Q: Question

Change the number of measurement times

When we open the session again after closing the session, the number of runs of a certain measurement (e.g. slow, medium, high Slam or Wiggle) changes.

What is the reason? Does this matter influence the result of measurements?

### A: Answer

The numbers in the top of the screen are currently updated when a new measurement is added, when the session is opened, or when runs are disabled – not upon importing. The run counts will not influence the data. Although we have not noticed this observation, there should be no influence on the data itself. Please confirm that the total number of runs should be constant, and only shifts from slow to medium or similar other combinations are observed. Wiggle, Push and Sweeps should not change.